



A hand-drawn diagram of a handheld device, possibly a remote control or a small handheld computer. The device is divided into two main sections. The upper section, labeled 62, contains a display area labeled 64. The display shows the word "DISCOVER" in large capital letters, followed by a series of characters "0000 1111 0000" and the name "JOHN DOE" below it. The lower section, labeled 30, contains a control knob labeled 43, a large rectangular button labeled 52, and a smaller rectangular button labeled 56.

FIG. 7A




FIG. 7B




FIG. 8




FIG. 9

